

AN-CU				
Denomination: CEILING ANCHOR	Codes: AN-CU			
Reference: FT ANCU-en	Date: 28/03/19	Revision: 3	Page: 1 de 4	
	AN-CU			
CHAR	ACTERISTICS			
Wedge-type, hammer-drive, metal anchor.Used on solid base materials.		CE	6	
• Easy installation.	European Techni	ical Assessment		

- Suitable for (static or almost static) medium loads.
- Tamper-proof solution.
- Installation through the element to be fixed.



APPLICATION EXAMPLES



• Examples: Suspensions from concrete ceilings attaching slit-steel straps, punched band, nonius system hanger or wood battens.

BASE MATERIAL





AN-CU			
Denomination: CEILING ANCHOR	Codes: AN-CU		
Reference: FT ANCU-en	Date: 28/03/19	Revision: 3	Page: 2 de 4

1. RANGE

DENOMINATION	РНОТО		COATING	DESCRIPTION
AN-CU			ZINC	Fixing element used in insulation panels, without nail.
ITEM	COMPONENT	MATERIAL		
1	BODY	Carbon steel class 4.8		
2	PIN	Carbon steel class 8.8		



AN-CU				
Denomination: CEILING ANCHOR	Codes: AN-CU			
Reference: FT ANCU-en	Date: 28/03/19	Revisio	n: 3 F	Page: 3 de 4
1.1 AN-CU	CEILING ANCHOR			
8			Material	
			A (Z
	Sizes			
	CODE		ANCU06040	ANCU06070
Effective depth	h _{ef} ≥	[mm]	3	2
Thickness of fixture	t _{fix}	[mm]	0 - 5	0 - 35
Nominal diameter of drill bit	d _o	[mm]	6	
Depth of the drilled hole	h₁≥	[mm]	40	
Minimum thickness of base material	h _{min}	[mm]	8	ט
Minimum spacing	S _{min}	[mm]	200	
	A A A A A A A A A A A A A A A A A A A		do do	
	RESISTANCES			
CODE Characteristic resistance all load directions (F _{Rk}) [kN]				
ANCU06040	ANCU06040 3.0			
ANCU06070				
ANCU06040 ANCU06070	Design resistance al	1,6	(r _{Rd}) [KIV]	
CODE	Maximum load recommen	ded all load dire	ections (F _{rec}) [kN]	
ANCU06040 ANCU06070		1,2		



AN-CU			
Denomination: CEILING ANCHOR	Codes: AN-CU		
Reference: FT ANCU-en	Date: 28/03/19	Revision: 3	Page: 4 de 4

INSTALLATION PROCEDURE		
	Check the concrete base is compact and porosity is insignificant. Drill to the specified diameter and depth values in previous table. Use drill in hammer mode. In case of hollow materials do not use the hammer mode to prevent damages inside the base material. Reduce the speed when are about to finish the drill.	
	Clear the drill holes completely of dust and fragments. Use air pump and brush.	
	Set up the fixture and the anchor. Hammer hit the flat surface on the top of the anchor as it shows the figure. Avoid hitting the nail, otherwise the anchor won't expand as it should.	
<2.5mm	Once the anchor is in contact with the fixture, hit the anchor in the nail as its showed in the figure. Insert the nail until the nail protrude at most 2,5 mm. The anchor is set up.	